

JJC SR-RC4

Remote Commander

English Manual Instruction

■ Getting started

This is SR-RC4 REMOTE COMMANDER to expand recording scenes for many ZOOM products such as H4n. You can make operation in hand the main unit placed in a distance location. Please read through the main unit operation manual before you start operation.


■ Specifications

Dimensions: Approx. 90.3 X 40.8 X 11.2 mm

Length of cable: 2m

Attachment: Operation Manual

■ The names and functions of each part



① **[REC] button and [REC] Indicator (Red)**

[REC] button is used to make setting of recording standby and putting a mark.

Indicator turns red during recording and blinks during recording standby.

② **[STOP] button**

Stop operation of recording and playback.

③ **[PLAY/PAUSE] button**

Make operation of recording and playback, also use for a temporary stop and re-start operation.

④ **[REW] button**

Make selections of rewinding and files.

⑤ **[FF] button**

Make selections of fast forwarding and files.

⑥ **RECLEVEL [+/-]**

Adjust recording level.

⑦ **VOLUME [+/-]**

Adjust recording level.

⑧ **INPUT [MIC][1][2] buttons and INPUT Indicator(Green, Yellow, Red)**

Make selections of input source. The indicator of the selected input button turns green light on.

*Button operation in detail: see the main unit operation manual.

⑨ **Remote commander jack**

Plug the jack in to the remote commander's jack.

■ SAFETY PRECAUTION / Usage precaution

The SR-RC4 is a precision instrument. Do not exert undue pressure on the switches and other controls. Also take not to drop the unit, and do not subject it to shock or excessive pressure. Please do not pull the cable and the jack strongly.

If you use the SR-RC4 in following environment, that may cause failure or troubles to the SR-RC4. Please avoid using there.

- Extremely hot or cold temperature
- Close to a heater, oven, radiator (heat source)
- Very high humidity, closer to shower or steam (covered with drops)
- Sandy or dusty

Avoid pouring and liquid (water, juice, or alcohol) and inserting.

How to take care of SR-RC4

Use a soft, dry cloth to clean the SR-RC4. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, wax, or solvents (such as paint thinner or cleaning alcohol).

JJC is a trademark of Shenzhen JinJiaCheng Photography Equipment Co., Ltd

ZOOM is a trademark of ZOOM Corporation.

